

Do's

DO spread bed joints

Spread across the mortar bed joints to a balanced thickness

DO smoothen Joints

All exposed joints need to be tool smoothly, marginally concave

DO follow guidelines

Adhere strictly to control height guidelines

DO place within cores

All the vertical reinforcements need to be placed centrally within



Don'ts

DON'T abandon

Do not abandon any mortar scrapes or slushes into joints

DON'T over channel

Do not over channel any bed joints or use cracked or broken units

DON'T let joints collapse

Do not let vertical joints to collapse on the centerline

DON'T adjust after starting

Do not adjust any unit after mortar starts to set up

